

AL-MOBIVAC vakuumløfter



AL-MOBIVAC vacuum lifter for handling of porous concrete etc.

AL-MOBIVAC is the perfect vacuum system for porous tiles and stones due to the extreme vacuum flow. Ensures a gentle and accurate placement of tiles. Picking up slaps is also possible.

Equipped with adjustable handlebar and quick coupler for suction pads with 90° swivel suspended to ensure perfect positioning of the slaps.

AL-MOBIVAC is powered by the integrated Honda generator that powers the powerful vacuum turbine and ensures safe and fast (within 0.5 seconds) adhesion to even very porous tiles

AL-MOBIVAC is standard equipped with large pneumatic tires, and the lever bar principle with a large handle enables single-person laying of all types of tiles or picking from full pallets of tiles.





AL-MOBIVAC has an integrated HONDA generator which powers the vacuum turbine and is thus fully independent of the power grid.

Technical data:

- Max load (SWL): 200 kg (depends on size of suction cup)
- Voltage 220v
- Surrounding temperature: +10 - +40°
- Manual valve for suction / release of load
- Safety devices:
 1. Manometer
- Dimensions (LxWxH): 2300 x 700 x 1300 mm
- Weight excl suction cup: 100 kg

Article no. Description

100.100 AL-MOBIVAC

AL-MOBIVAC Suction pads	Suction pad size mm	Ring size mm	SWL kg	Article No. suction pad complete	Article No. replacement ring
	ø300	20x20	50 kg	320.104	300.003
	ø350	40x20	75 kg	320.100	300.005
	ø440	40x20	100 kg	320.101	300.006
	200x470	20x20	70 kg	320.102	300.015
	300x400	20x20	90 kg	320.103	300.027
	Suction beam	ø200 mm	60 kg	320.105	
AL-MOBIVAC Accessories	Description				Article No.
	Kit for AL-MOBIVAC , to use the vacuum lifter for two man handling as a AL-MANOLAY				330.111